

Fig 1 TCS4600 BASE PART



Fig 1 TCS4600 BASE PART

NºFig	Referencia	Descripción	qty	BOM No.	NºFig	Referencia	Descripción	qty	BOM No.
1	TCS4600.04.00-00	right cover assembly	1	05.01.04.1406	35	TCS4600.02.00-1	guide flow cover	1	04.01.20.00206
2	YD38-3.04.00-16	screw M5×40	1	01.01.4151	36	TCS4600.02.00-00	starter assembly	1	05.01.04.1407
3	YD38-3.04.00-13	shield pipe	1	06.06.020	37	GB/T845	tapping screw ST4.8×14	1	01.01.4111
4	YD38-3.04.00-12	pipe	1	06.06.207	38	GB/T96	washer 5	1	01.04.0161
5	GB/T119.2	pin 3×14	1	01.05.0171	39	YD45.02.00-2	starter palte	1	04.01.07.07308
6	YD45.04.00-24	tightener screw	1	06.06.206	40	YD45.02.00-5	start coil spring	1	06.03.050
7	YD45.04.00-25	tension block	1	06.06.202	41	YD38-5.02.00-4	start handle	1	04.01.06.05109*
8	YD45.04.00-11	tensioner cover plate	1	06.02.103	42	YD45.02.00-7	start stretching wire	1	04.03.0001608
9	GB/T845	tapping screw ST4.2×9.5	4	01.01.1391	43	TCS4600.02.01-00	starter cover	1	04.01.20.00802
10	TCS4600.04.00-2	front damper	1	04.01.20.00906	44	YD45.03.00-1	shock rubber	1	03.01.2.044
11	YD38-3.04.00-9	brake torsion rod spring	1	06.03.064	45	YD46.03.01-00	base	1	04.01.10.00505
12	YD45.3.04.00-13	washer 5.2×20×1.2	1	06.02.111	46	YD45.03.02-00	shock rubber gland	2	03.01.1.001
13	GB/T6183.1	nut M5	1	01.03.0113	47	YD50.00.00-9	screw	2	06.06.219
14	YD38-3.04.00-6	spring base	1	06.02.013	48	YD45.00-00-2	dust cover	2	04.01.04.08706
15	YD38-3.04.00-5	front damper spring	1	06.03.051	49	YD38-3.03.02-2	anti-drop plate	1	04.01.07.04408
16	YD38-3.04.00-4	main lever	1	04.01.04.09908	50	JB/T7757.2	O sealing 24.7×3.55	1	03.01.2.100
17	YD38-3.04.00-3	secondary pull-rod	1	04.01.04.01808	51	TCS4600.03.02-1	petrol cover	1	04.01.20.00306
18	GB/T119.2	pin 3×9	3	01.05.0161	52	YD45.03.00-2	fuel tube	1	03.01.2.065
19	YD45.04.00-14	brake control rod	1	06.02.079	53	YD45.03.00-15	fuel tube circlip	1	06.03.098
20	YD45.04.00-9	brake spring	1	06.03.059	54	YD45.03.03-00	petrol filter componets	1	04.01.07.08406*
21	YD45-4.04.00-12	brake strap	1	06.03.057	55		balancer	1	04.01.07.07208*
22	YD45-4.04.00-1	brake spring cover plate	1	04.01.10.02006	56	YD38-3.03.00-3	balancer root	1	03.01.2.063
23	YD45.04.00-26	tension gear	1	06.06.196	57	YD45.03.00-25	throttle rod	1	06.03.076
24	YD45.01.00-16	chain guide block	1	04.01.07.03306	58	YD45.03.00-11	trigger	1	04.01.07.02206
25	TCS4600.04.01-00	right cover	1	04.01.20.00702	59	YD45.03.00-12	trigger torsion rod spring	1	06.03.007
26	TCS4600.04.00-7	dust shield	1	03.01.2.146	60	GB/T119.2	pin6×22	1	01.05.0181
27	YD38-3.04.00-7	heavy block spring	1	06.03.080	61	TCS4600.03.00-14	handle cover	1	04.01.20.01006
28	YD38-3.04.02-00	heavy block	1	04.01.04.09806	62	YD45.03.00-13	trigger control rack	1	04.01.07.03006*
29	GB/T6177.1	nut M8	2	01.03.0052	63	GB/T845	tapping screw ST4.2×22	1	01.01.4122
30	TCS4600.05.01-00	air filter lock nut	1	04.01.20.00106	64	YD38-3.01.11.04-00	extinction switch	1	02.05.16*
31	YD45-7.00.00-1	air filter cover	1	04.01.20.00608	65	YD45-2.06.00-00	front handle assembly	1	06.06.150
32	GB/T2672	screw M5×16	9	01.01.3111	66	GB/T845	tapping screw ST4.8×16	4	01.01.3161
33	TCS4600.05.00-1	upper cover plate	1	04.01.20.00508	67	YD45-4.03.00-11	scavenge nozzle	1	03.01.2.140
34	TCS4600.00.00-6	idle adjusting guide set	1	03.01.2.141	68	YD45-4.03.00-13	pump tube	1	03.01.2.004
					69	YD38-3.00.00	Primer bulb	1	04.01.04.08908

Fig 2 TCS4600 ENGINE PART

Fig 2 TCS4600 ENGINE PART

NºFig	Referencia	Descripción	qty	BOM NO.	NºFig	Referencia	Descripción	qty	BOM NO.
1	YD45.01.02-1	cylinder	1	05.01.02.034	39	YD45.01.00-23	sponge transition coil	1	12.02.0001
2	GB/T6170	nut M5	2	01.03.0091	40	YD45.01.00-13	nozzle	1	03.01.2.061
3	GB/T93	washer 5	15	01.04.0091	41	YD45.01.00-16	chain guide block	1	04.01.07.03306
4	GB/T97.1	washer 5	13	01.04.0121	42	GB/T900	double-screw bolt AYM8-M8×26-8.8	2	01.02.1061
5	YD45.01.09-1	muffler cover plate	1	06.02.096	43	YD45.01.13.01-00	clutch	1	05.01.04.0034
6	YD45.01.09.01-00	muffler body	1	06.06.165	44	YD45.01.13.01-2	shoe block	3	06.01.016
7	YD45.01.00-2	muffler sealing plate	1	08.023	45	YD45.01.13.01-1	retainer	1	06.01.004
8	YD45.01.00-24	muffler connecting screw	2	06.06.227	46	YD45.01.13.01-3	clutch spring	1	06.03.047
9	GB/T6191	screw M5×20	6	01.01.2141	47	YD45.01.00-19	clutch adjusting washer	1	06.02.061
10	YD45.01.11.04-00	spark plug	1	02.35.08	48	YD45.01.00.10-00	needle bearing 12×15×14.5	1	01.05.1140
11	YD45.01.02-2	air intake tube sealing plate	1	08.012	49	YD45.01.13-1	clutch shell	1	06.05.014
12	YD45.01.02.01-00	air intake tube	1	03.01.2.052	50	YD45.01.00-26	sprocket	1	06.06.126
13	GB/T2672	screw M5×12	4	01.01.3181	51	YD45.01.00.06-00	worm	1	04.01.07.12208
14	YD45.01.00-17	hold coil	1	06.02.006	52	YD45.01.00-15	cover plate	1	04.01.07.05406
15	YD45.01.00-1	cylinder sealing plate	1	08.017	53	YD45.01.00.09-00	oil seal 15×26×4.5	1	03.01.2.086
16	YD45.01.03-2	piston ring	2	06.06.096	54	GB/T276	bearing 6202D grade 15×35×11	2	01.05.1260
17	YD45.01.03-1	piston	1	06.06.089	55	YD45.01.00-8	cushion block	1	03.01.2.042
18	YD45.01.03-4	piston pin circlip	2	06.03.032	56	YD45.01.00-7	choke rod fixation root	1	03.01.2.021
19	YD45.01.03-3	piston pin	1	06.06.104	57	YD45.01.00.03-00	choke rod	1	04.01.07.05006
20	YD45.01.03-5	needle bearing ring	2	06.06.055	58	YD45.01.00-11	right shock block	1	03.01.2.093
21	YD45.01.03.01-00	crank shaft components	1	06.05.011	59	YD45.01.00.07-00	shock seat	3	03.01.2.047
22	YD45.01.03.02-00	needle bearing 11×15×12.5	1	01.05.1130	60	YD45.01.00.01-00	air intake tube support	1	04.01.07.05806
23	GB/T1099	semicircular key 3×3.5×10	1	01.06.0031	61	YD45.01.00-4	tie plate	1	08.006
24	YD45.00.00-4	conical spring base	1	06.03.082	62	YD45.01.00-3	sealing plate of air intake support	1	08.014
25	YD45.00.00-3	conical spreader base	1	04.01.07.13206	63	YD45.01.00-14	air intake tube flange	1	04.01.07.05706
26	GB/T845	tapping screw ST4.8×16	4	01.01.3161	64	YD45.01.06-00	carburetor	1	06.06.137*
27	YD45.00.00.01-00	chain shield	1	04.01.07.07006	65	YD45.01.00.02-00	air intake socket	1	06.06.090*
28	GB/T2672	screw M5×16	1	01.01.3111					
29	YD45.01.01.02-2	aeration jet	1	03.01.2.098	66	TCS4600.01.08-00	air filter	1	04.01.20.01300
30	YD45.01.01.02-3	aeration jet circlip	1	06.03.069	67	GB/T899	double-screw bolt GM5-M5×30	1	01.02.1081
31	YD45.01.00-22	sponge transition block	1	12.02.0002	68	YD45.01.00-5	cushion of air intake socket	1	06.06.114
32	YD45.01.00-21	pinion rack	1	06.02.012	69	GB/T2672	screw M5×50	2	01.01.3021
33	GB/T2672	screw M5×10	5	01.01.3101	70	YD45.01.01.02-1	right case	1	06.04.079
34	YD45.01.00.04-2	oil filter screen	1	04.01.07.05608	71	YD45.01.00-6	dust plate	1	03.01.2.030
35	YD45.01.00.04-1	oil filter	1	06.06.115	72	GB/T119.2	pin 5×10	3	01.05.0071
36	YD45.01.00-12	oil tube	1	03.01.2.034	73	YD38-3.01.11.03-00	earth wire	1	02.34.30
37	GB/T2672	screw M4×14	2	01.01.3071					
38	YD45.01.15-00	oil pump	1	06.06.001					

Fig 2 动力部分 TCS4600 ENGINE PART

编号	代号	Descripción	qty	BOM NO.
74	YD45.01.00-10	left shock block	1	03.01.2.095
75	GB/T6191	screw M5×25	5	01.01.3081
76	YD45.01.00-20	oil shield	1	06.02.098
77	GB/T93	washer 4	2	01.04.0191
78	GB/T2672	screw M4×8	2	01.01.3091
79	GB/T2672	screw M4×10	4	01.01.3061
80	YD45.01.10.01-00a	flywheel assembly	1	02.36.02*
81	GB/T6177.2	nut M8×1	1	01.03.0073
82	JB/T7757.2	O sealing 20×3.1	1	03.01.2.110
83	YD45.01.00.05-2	anti-drop plate	1	04.01.07.04408
84	TCS4600.03.03-1	oil cover	1	04.01.20.00406
85	YD45.01.01.01-3	suction tube circlip	2	06.03.025
86	YD45.01.01.01-2	suction tube 2.5×6×105	1	03.01.2.024
87	YD45.01.01.03-00	suction jet	1	04.01.07.13306
88	YD45.01.01.01-1	left case	1	06.04.078
89	GB/T893.1	shield ring 35	1	01.04.1011
90	YD45.01.00.08-00	oil seal 15×35×4.5	1	03.01.2.087
91	YD45.01.11.01-00	igniter	1	02.35.05
92	YD45-7.01.11.02-00	extinction conductor	1	02.34.60
93	TCS4600.01.11-3	igniter cap	1	03.01.2.147
94	YD45.00.00-9	dust cover	2	04.01.07.04306
95	YD45.01.01-1	case body sealing plate	1	08.020
96	YD45.01.00-18	damper	1	06.02.015