

PARTS LIST

BL9000

CONTENTS

1. FRAME & BLOWER	1 ~ 4
2. ENGINE (CYLINDER, CRANKCASE)	5 ~ 8
3. ENGINE (CARBURETOR, FUEL TANK).....	9 ~ 12
4. ACCESSORIES, OPTIONAL PARTS	13 ~ 14


2017. 06.



MARUYAMA


P/N 524418-1

1. BL9000
FRAME & BLOWER



Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	395867	BL9000	1	
1-2	278382	Engine	1	CE800/02
1-3	275864	Fan Case (E)	1	
1-4	275868	Fan Case (S)	1	
1-5	276361	Collar	1	
1-6	100749	Fastener	4	#7
1-7	109051	Clamp	1	
1-8	082697	Tapping Screw	1	M5x10
1-9	275966	Plug B	2	
1-10	131523	Tapping Screw	2	M5x20
1-11	130420	Tapping Screw	12	M5x25
1-12	261189	Washer	1	6x16.5xt1.2
1-13	275965	Plug A Comp	2	
1-14	275967	Spring	2	2.9-50L
1-15	127228	Nut	2	M6
1-16	275870	Flexible Pipe Ass'y	1	Incl.17,18
1-17	275871	Elbow Pipe	1	
1-18	275873	O-Ring	1	V95
1-19	275874	Fan	1	
1-20	275877	Cap Screw	4	M6X25
1-21	276456	Knapsack Band	1	
1-22	275965	Plug A Comp	2	
1-23	275967	Spring	2	2.9-50L
1-24	127228	Nut	2	M6
1-25	275878	Throttle Ass'y	1	Incl.26-44
1-26	276459	Knob Bolt	1	M6x40
1-27	276297	Throttle Wire Ass'y	1	
1-28	275881	Throttle Case A	1	
1-29	272721	Lever	1	
1-30	273211	Screw	1	5x18
1-31	272724	Spring Washer	1	
1-32	275883	Link	1	
1-33	230662	Nut	1	M5
1-34	275885	Lever	1	
1-35	275887	Spring	1	
1-36	275888	Throttle Case B	1	
1-37	275890	Stop Switch	1	
1-38	222138	Cover, Switch	1	
1-39	235679	Screw	4	
1-40	131523	Tapping Screw	1	M5x20
1-41	275891	Band Ass'y	1	Incl.42,43
1-42	275892	Band (A)	1	
1-43	275894	Band (B)	1	
1-44	127298	Nut	1	M6
1-45	125717	Pin	4	


1. BL9000
 FRAME & BLOWER



Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-46	276460	Cushion Pad	1	
1-47	275898	Flame	1	
1-48	275900	Guard	1	
1-49	100749	Fastener	5	#7
1-50	086069	Tapping Screw	1	M6x12

2. BL9000 ENGINE (CYLINDER, CRANKCASE)


2-30	2-31~2-39
2-32	2-33~2-39
2-34	2-35~2-37



Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	278382	Engine	1	CE800/02
2-2	275765	Cylinder Comp	1	
2-3	275760	Gasket	1	
2-4	261246	Cap Screw	4	M5x25
2-5	276109	Insulator	1	
2-6	276110	Gasket	1	
2-7	277832	Cap Screw	4	M5x30
2-8	278384	Muffler Ass'y	1	
2-9	131523	Tapping Screw	5	M5x20
2-10	277462	Grommet	1	
2-11	134368	Label	1	
2-12	264223	Cap Screw	1	M5x40
2-13	276111	Gasket	1	
2-14	261607	Cap Screw	2	M5x16
2-15	276154	Cap Screw	2	M6x70
2-16	276112	Crankcase	1	
2-17	276117	Bearing	2	
2-18	276118	Oil Seal	1	
2-19	262565	Oil Seal	1	ISCD15257
2-20	276119	Snap Ring	1	
2-21	234636	Cap Screw	4	M5x35
2-22	277475	Piston	1	
2-23	275757	Piston Ring	2	
2-24	278019	Piston Pin	1	
2-25	278471	Bearing,Needle	1	KBK12x15x14.3x5
2-26	276122	Cir Crip	2	
2-27	276123	Shaft Comp	1	
2-28	276129	Adapter	1	
2-29	261076	Woodruff Key	1	3x10
2-30	276100	Magneto Ass'y	1	Incl.31-39
2-31	276032	Rotor	1	
2-32	276465	Ignition Coil Ass'y	1	Incl.33-39
2-33	267401	Coil	1	
2-34	276466	Spark Plug Wire Ass'y	1	Incl.35-37
2-35	276467	Spark Plug Wire	1	
2-36	282292	Plug Boot	1	
2-37	261075	Connector	1	
2-38	261072	Cap	1	
2-39	276468	Tube	1	
2-40	261076	Woodruff Key	1	3x10
2-41	276302	Nut	2	
2-42	281211	Cap Screw	2	M4x20
2-43	288264	Spark Plug	1	BPMR8Y
2-44	285549	Grommet	1	
2-45	285807	Grommet	1	


2. BL9000 ENGINE (CYLINDER, CRANKCASE)

2-30	2-31~2-39
2-32	2-33~2-39
2-34	2-35~2-37




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-46	281864	Lead	2	
2-47	276133	Ratchet	2	
2-48	277770	Clamp	1	
2-49	289481	Spacer	2	
2-50	262637	Return Spring	2	
2-51	262638	E-Ring	2	
2-52	276131	Starter Ass'y	1	Incl.53-63
2-53	276035	Reel	1	
2-54	276036	Washer	1	
2-55	276037	Spring	1	
2-56	276038	Spiral Spring	1	
2-57	276039	Washer	1	
2-58	276040	Plate	1	
2-59	276041	Screw	1	
2-60	276042	Rope Ass'y	1	Incl.61-63
2-61	276043	Starter Rope	1	
2-62	262633	Starter Grip	1	
2-63	262981	Cap	1	
2-64	275877	Cap Screw	4	M6X25
2-65	268940	Screw	3	M5x18
2-66	276163	Top Cover	1	

3. BL9000
ENGINE (CARBURETOR, FUEL TANK)






Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	276045	Carburetor Ass'y	1	Incl.2-20
3-2	263739	Pump Body	1	
3-3	262991	Purge Body	1	
3-4	262992	Cover Plate	1	
3-5	261874	Primer Bulb	1	
3-6	283905	Diaphragm, Meterring	1	
3-7	262993	Gasket	1	
3-8	262994	Diaphragm,Fuel Pump	1	
3-9	282576	Gasket	1	
3-10	286900	Jet	1	
3-11	261871	O-Ring	1	
3-12	261876	E-Ring	1	
3-13	264678	Washer	1	
3-14	261658	Swivel	1	
3-15	261875	Screw	1	
3-16	264677	Bracket	4	
3-17	261657	Packing	1	
3-18	262996	Screw	4	
3-19	261877	Adapter	1	
3-20	261878	Nut	1	
3-21	277762	Label	1	
3-22	276134	Gasket	1	
3-23	276150	Case Ass'y	1	Incl.24-29
3-24	276151	Case Body	1	
3-25	277830	Sleeve	2	
3-26	276152	Valve	1	
3-27	276153	Lever	1	
3-28	284816	Washer	1	6.4x11x0.15
3-29	269032	Screw	1	
3-30	274106	Cap Screw	2	M5x55
3-31	276463	Air Cleaner Box Ass'y	1	Incl.32-37
3-32	276155	Air Cleaner Box Cover	1	
3-33	276143	Element	1	
3-34	276139	Air Cleaner	1	
3-35	276157	Air Cleaner Case	1	
3-36	276159	Air Cleaner Box Ass'y	1	
3-37	276999	Knob Bolt	2	
3-38	276161	Intake Pipe	1	
3-39	277547	Clump Ass'y	1	#55
3-40	086071	Tapping Screw	4	M6x16
3-41	277548	Clump Ass'y	1	#90
3-42	134755	Tank Ass'y	1	Incl.43-53
3-43	277090	Fuel Tank	1	
3-44	131319	Tank Cap Ass'y	1	Incl.45
3-45	287058	Gasket	1	

3. BL9000
ENGINE (CARBURETOR, FUEL TANK)



Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	276092	Fuel Pipe Pick-up Ass'y	1	Incl.47-52
3-47	276355	Fuel Pipe Ass'y	1	Incl.48-50
3-48	268065	Grommet	1	
3-49	261590	Breather	1	
3-50	261117	Clip	1	
3-51	267328	Fuel Filter Ass'y	1	
3-52	261117	Clip	1	
3-53	131328	Clamp	1	
3-54	127221	Screw	2	M6x16
3-55	125277	Nut	2	
3-56	134383	Label	1	
3-57	134479	Label	1	BL9000

4. BL9000
ACCESSORIES, OPTIONAL PARTS



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	275906	Flexible Pipe	1	
4-2	275908	Pipe Ass'y	1	Incl.3-6
4-3	275909	Flexible Pipe	1	
4-4	275914	Straight Blow Pipe	1	
4-5	275916	Blow Pipe	1	
4-6	276352	Blow Pipe	1	
4-7	130208	Clamp Ass'y	2	#105
4-8	128924	Clamp	2	
4-9	288652	Combi Box Spanner	1	13x19 L=190
4-10	134385	Instruction Manual	1	BL9000
4-11	278009	Blow Pipe	1	