

NºFig.	Referencia	Descripción	Nº(pcs)
1	85BABC04-20	screw	4
2	8069-900002	back cover	1
3	85BABC04-16	screw	22
4	8030-900001	washer1	1
5	8053-900005	front finser guard	1
6		namaplard	1
7		warning label	1
8	8001-900001	left housing	1
9	8072-900001	brake block	1
10	85BABC04-16	screw	2
11	8036-920001	brush holder	1
12	8023-920001	carbon brush cove	2
13	8035-930001	carbon brush	2
14	808-60802	bearing	1
15	85BABC04-10	screw	2
16	8030-900003	field	1
17	8053-900004	wind screen	1
18	8013-900004	armature	1
19	8072-900002	block	1
20	8031-900001	brake wheel	1
21	85BABC04-10	screw	5
22	8030-900003	washer3	2
23	8072-900002	block	1
24	8060-900002	extension spring	1
25	8050-900001	brack hinge	1
26	8060-900001	extension spring	1
27	8038-900001	oil pipe 1	1
28	8160-900001	ump housing asse	1
28-1	8146-131001	oil pump housing	1
28-2	8028-900001	rubber gasket	1
28-3	8023-900003	oil pump sets	1
29	8160-900002	pump core assem	1
29-1	8146-900002	oil pump core	1
29-2	8138-900004	oil pump pin	1
29-3	8052-900003	oil pump gear	1
29-4	8025-900003	o type ring	1
30	8038-900002	oil pipe 2	1
31	8138-900003	pin	3
32	8032-900002	microswitch	1
33	8039-900002	motor support	1
34	8030-900005	wash 5	1
35	8052-900001	small gear	1
36	8WSB-04	spring washer	1
37	8NAB-08	nut	1
38	8160-900003	big gear assembly	1
38-1	8057-900001	bolt	1
38-2	8DB-600002	bearing	1
38-3	8020-900001	spindle	1
38-4	8052-900002	big gear	1
38-5	8DB-600102	bearing	1
38-6	8081-900002	rubber sheath	1
40	8053-900006	rubber sheath	1
41	8155-900002	spiked pumper	1
42	8025-900004	rubber ring	1
43	8069-900001	Shield	1
44	8155-900001	Sprocket	1
45	8CC-10	retaining spring	1
46	8131-900001	spring	1
47	8002-90001	right housing	1
48	85EABC04-12	screw	3
49	8053-900002	Spiral plate	1
50	8069-900005	chain clamp plate	1
51	8060-900004	spring	1
52	8160-900006	knob assembly	1
52-1	8058-900001	knob 1	1
52-2	8058-900002	knob 2	1
52-3	8075-900001	insert nut	1
53		label	1
54	8136-900002	Rubber cork	5
55	8047-900001	brake belt	1
56	8DB-600002	bearing	1
57	8030-900004	washer 4	1
58	8160-900004	oil tank assembly	1
58-1	8148-900001	oil tank sheath	1
58-2	8025-900001	Ring	1
58-3	8060-900005	spring	1
58-4	8081-900001	iter screen stoppe	1
58-5	8147-900001	oil tank	1
59	8160-900005	l tank cap assemb	1
59-1	8069-900003	oil tank cap	1
59-2	8148-900002	ber sheath on oil t	1
59-3	8025-900002	o type ring	1
60	8027-920001	connecting wire	1
61	8057-900002	pull rod	1
62	8058-900003	switch button	1
63	8032-900003	switch	1
64	8033-900001	capacitor	1
65	8053-810001	cord clamp plate	1
66	85BABC04-12	screw	2
67	8023-900001	cord sheath	1
68	8029-900001	supply cord	1
69	91P056X	saw chain	1
70	8053-900001	adjusting board	1
71	1165DEAP1X	guide bar	1
72	8023-900006	bushing	1
73	8030-900002	washer 2	1
74	8WSB-04	spring washer	1
75	8074-900005	screw	1
76	8023-900002	blade cover	1

