

# PARTS LIST

## BCL2250C-RS2

### CONTENTS


1. MAIN BODY .....	1 ~ 2
2. BEARING HEAD .....	3 ~ 4
3. ENGINE .....	5 ~ 8
4. CARBURETOR, FUEL TANK .....	9 ~ 10

2009. 01.




P/N 522733

1. BCL2250C-RS2  
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	363584	BCL2250C-RS2	1	
1-2	218868	Clutch Case Ass'y	1	Incl.3-7
1-3	218869	Clutch Case	1	
1-4	012649	Bearing	1	#6201ZZ
1-5	140273	Snap Ring	1	#12
1-6	016732	Snap Ring	1	#32
1-7	218492	Clutch Drum	1	
1-8	092550	Bolt	1	M5x25-7T
1-9	224120	Driveshaft Tube	1	
1-10	215985	Driveshaft	1	
1-11	215995	Shaft Grip	1	
1-12	222952	Throttle Trigger	1	
1-13	223051	Throttle Cable	1	300L
1-14	223052	Plastic Tube	1	#10x125L
1-15	222937	Loop Handle Ass'y	1	Incl.16-19
1-16	222938	Loop Handle	1	Incl.17
1-17	081028	Nut	4	M5
1-18	216004	Packing	1	
1-19	222142	Screw	4	M5x28
1-20	227061	Label	1	BCL2250C-RS2
1-21	220810	Label	1	
1-22	225382	Label	1	
1-23	817002	Bolt	4	M5x20

2. BCL2250C-RS2  
BEARING HEAD




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	215986	Bearing Head Ass'y	1	Incl.2-8
2-2	215987	Case,Bearing	1	
2-3	215988	Attaching Shaft	1	
2-4	215989	Bearing	2	#608DD
2-5	215990	Spacer	1	
2-6	215991	Washer	1	
2-7	015845	Spring Washer	1	M8
2-8	215992	Attaching Shaft Adapter	1	
2-9	092550	Bolt	1	M5x25-7T
2-10	089736	Bolt	1	M5x10
2-11	220246	Guard Ass'y	1	Incl.12-18
2-12	215999	Guard	1	
2-13	216000	String Cutter	1	
2-14	096043	Bolt	2	M5x16
2-15	012501	Spring Washer	2	M5
2-16	081027	Nut	2	M5
2-17	089559	Bolt	1	M6x40
2-18	081030	Nut	1	M6
2-19	210418	Box Spanner	1	13x19x(+)
2-20	022865	Double-ended Wrench	1	8x10
2-21	210181	Lever Handle	1	3.5x170L
2-22	230559	Instruction Manual	1	<ES>
2-23	230558	Instruction Manual	1	<PT>
2-24	229935	Semi-Auto Head (R)	1	
2-25	522733	Parts List	1	BCL2250C-RS2

### 3. BCL2250C-RS2 ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	858531	Engine	1	BE230/112
3-2	266249	Cylinder	1	New gasket required
3-3	283420	Gasket	1	
3-4	267290	Cap Screw	2	M5x20
3-5	265802	Insulator	1	New gasket required
3-6	267049	Gasket	1	
3-7	265924	Cap Screw	2	M5x25
3-8	281524	Muffler	1	
3-9	266264	Cap Screw	2	M5x50
3-10	280266	Gasket	1	
3-11	267561	Label	1	
3-12	285246	Label	1	BE230(REVERSE2)
3-13	261878	Nut	1	
3-14	267177	Screw	1	M5x16
3-15	261250	Cap Screw	4	M5x20
3-16	267060	Top Cover Ass'y	1	
3-17	265694	Label	1	
3-18	264022	Knob	1	
3-19	267063	Crankcase	1	
3-20	280488	Bearing	2	PPL 6001
3-21	261492	Oil Seal	1	ISCD12287
3-22	261386	Oil Seal	1	ISCD12227
3-23	055185	Snap Ring	1	#28
3-24	261612	Cap Screw	3	M5x30
3-25	283265	Piston	1	
3-26	263789	Piston Ring	1	
3-27	281185	Piston Pin	1	
3-28	261037	Bearing,Needle	1	KBK8x11x11.8x1
3-29	261576	Clip,Piston	2	
3-30	267193	Crankshaft/Conn.Rod Ass'y	1	
3-31	264025	Clutch Ass'y	1	Incl.32,33
3-32	264026	Clutch Shoe	2	(2)Required
3-33	264028	Spring,Clutch	1	
3-34	264505	Bolt	2	
3-35	261189	Washer	2	6x16.5x1.2
3-36	261777	Wave Washer	2	
3-37	283025	Fan Cover	1	
3-38	267391	Magneto Ass'y	1	Incl.39-47
3-39	261356	Rotor/Fan	1	
3-40	267400	Ignition Coil Ass'y	1	Incl.41-47
3-41	267401	Coil	1	
3-42	267403	Spark Plug Wire Ass'y	1	Incl.43-45
3-43	267404	Spark Plug Wire	1	
3-44	261074	Plug Boot	1	
3-45	261075	Connector	1	


### 3. BCL2250C-RS2 ENGINE





Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	261072	Cap	1	
3-47	269418	Insulator	1	
3-48	261076	Woodruff Key	1	3x10
3-49	261417	Nut,Rotor	1	M8
3-50	280381	Spacer	2	
3-51	261256	Cap Screw	2	M4x25
3-52	262483	Spark Plug	1	NGK BPMR6Y
3-53	267093	Wire,Lead	2	
3-54	261202	Grommet	1	
3-55	280925	Recoil Starter Ass'y	1	Incl.56-65
3-56	280922	Starter Ass'y	1	Incl.57-64
3-57	283411	Reel	1	
3-58	283412	Cam Plate	1	
3-59	280930	Spring	1	
3-60	280931	Spiral Spring	1	
3-61	267213	Screw	1	
3-62	280932	Starter Rope Ass'y	1	Incl.63,64
3-63	280933	Starter Rope	1	
3-64	267219	Starter Grip	1	
3-65	280934	Starter Pawl Ass'y	1	
3-66	265726	Cap Screw	3	M4x16
3-67	265409	Adapter	1	

4. BCL2250C-RS2  
 CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	267100	Carburetor Ass'y	1	Incl.2-15
4-2	261871	O-Ring	1	
4-3	267358	Main Jet	1	
4-4	262995	Gasket	1	
4-5	262994	Diaphragm,Fuel Pump	1	
4-6	263739	Pump Body	1	
4-7	262993	Gasket	1	
4-8	261873	Diaphragm,Metering	1	
4-9	262991	Purge Body	1	
4-10	261874	Primer Bulb	1	
4-11	262992	Cover Plate	1	
4-12	262996	Screw	4	
4-13	261876	E-Ring	1	
4-14	261658	Swivel	1	
4-15	264682	Screw	2	
4-16	261864	Gasket	1	
4-17	269052	Case Ass'y	1	Incl.18-23
4-18	269050	Case Body	1	
4-19	269028	Valve	1	
4-20	269029	Lever	1	
4-21	269032	Screw	1	
4-22	081028	Nut	1	M5
4-23	269051	Sleeve	2	
4-24	262720	Cap Screw	2	M5x55
4-25	269030	Element	1	
4-26	269027	Cleaner Cover	1	
4-27	269031	Screw	1	M5x12
4-28	267598	Fuel Tank Ass'y	1	Incl.29-39
4-29	267103	Fuel Tank	1	
4-30	262726	Fuel Tank Cap Ass'y	1	Incl.31
4-31	261105	Gasket	1	
4-32	261696	Breather Ass'y	1	
4-33	267309	Fuel Pipe Pick-up Ass'y	1	Incl.34-39
4-34	266955	Fuel Pipe Ass'y	1	Incl.35-37
4-35	261115	Grommet	1	
4-36	265469	Fuel Pipe	1	140L
4-37	263038	Return Pipe	1	3x6x85L
4-38	264653	Filter Ass'y	1	
4-39	261117	Clip	1	
4-40	264318	Pad	2	
4-41	263824	Pad	1	
4-42	261117	Clip	1	