







Picture Number	Quantity	Part number	Description
2	1	129624	ENGINE
3	6	128142	Bolt
4	1	125404	GASKET
5	3	127295	Screw
6	1	125405	FANCASE E ASSY
7	1	125410	FAN CASE S ASSY
8	1	119160	COLLAR
9	1	119161	BAND
10	10	129618	TAPPING SCREW
11	2	120615	BUFFER
12	1	128908	FAN
13	1	128910	RING
14	4	128911	BOLT
15	1	126327	THROTTLE ASSY
16	1	126729	THROTTLE ASSY
17	1	125756	THROTTLE
18	1	126734	THROTTLE WIRE ASSY
19	1	126733	FERRITE CORE
20	1	118811	HOLDER ARM
21	2	127297	TAPPING SCREW M5X20
22	1	122609	BAND
23	1	122414	HOLDER (A)
24	1	122416	HOLDER (B)
25	1	127298	NUT M6
26	1	127299	KNOB BOLT M6X30
27	1	127305	CLAMP
28	1	126049	CLAMP
29	1	127300	SCREW M5X18
30	1	125427	BACK PACK FROM A
31	1	125429	BACK PACK FRAME B
32	4	127301	BOLT M6X20
33	4	127228	NUT M6
34	1	125432	BAND ASSY
35	1	127728	SCREEN
36	2	127786	SCREW
37	1	101877	BUFFER
38	1	120616	COLLAR
39	1	120617	WASHER
40	3	127228	NUT M6
41	1	119177	PAD
42	4	100749	FASTENER
43	1	127707	FUEL TANK
44	2	125561	SCREW
45	1	129721	LABEL
46	1	267144	LABEL
47	1	266959	LABEL
48	1	125940	SEAL
49	1	125747	SEAL
50	1	121132	LABEL






Picture Number	Quantity	Part number	Description
2	1	649312	CYLINDER
3	1	415369	GASKET, CYLINDER
4	1	649314	PLATE
5	2	414427	CRANKCASE
6	1	414428	CRANKCASE
7	2	573908	PIN
8	2	649317	BEARING
9	2	414429	OIL SEAL
10	4	414431	BOLT-SOCKET
11	4	414430	BOLT-SOCKET
12	4	410897	SCREW
13	1	649321	PISTON
14	1	649322	PISTON PIN
15	1	649323	PISTON RING SET
16	1	649325	NEEDLE BEARING
17	1	414432	CRANKSHAFT ASS'Y
18	2	414433	SPACER
19	2	943307	SNAP RING
20	1	071695	KEY
21	1	649329	SHROUD
22	1	400923	SHROUD
23	1	415370	SCREW
24	1	414436	FLYWHEEL
25	1	415371	COIL ASS'Y
26	1	591532	SPARK PLUG CAP
27	1	591533	SPRING
28	1	998411	TUBE
29	1	649332	LEAD WIRE
30	1	649333	PLUG
31	1	649334	GROMMET
32	2	649335	BOLT
33	1	649336	NUT
34	1	400921	RECOIL ASSY
35	1	649370	PAWL
36	1	400919	PLATE
37	1	649371	RETAINER
38	1	649372	RECOILE HOUSING
39	1	400920	GRIP
40	1	649376	RECOIL REEL
41	1	649377	ROPE
42	1	649378	SPRING
43	1	400922	SPRING
44	1	649380	SCREW
45	1	649374	STARTING PULLEY
46	4	624845	SCREW
47	1	649381	NUT





Picture Number	Quantity	Part number	Description
1	1	412446	GASKET
2	2	400925	GASKET
3	1	649342	VALVE
4	1	649344	CARB ASSAY
5	1	649338	BRACKET
6	1	649339	GASKET
7	1	634350	GASKET
8	1	649343	COVER
9	1	649346	BODY
10	1	624429	LEVER
11	1	624430	FILTER
12	1	624431	FLOAT VALVE
13	1	624432	SCREW
14	1	624433	PIN
15	1	624434	SPRING
16	1	598415	ARM
17	1	577185	PUMP DIAPHRAGM
18	1	634357	DIAPHRAGM
19	2	577179	SCREW
20	4	649348	SCREW
21	1	577175	SNAP RING
22	1	577182	O-RING
23	1	649349	MAIN JET
24	1	624532	WASHER
25	1	400926	INSULATOR
26	1	649347	STOPPER
27	1	577361	SCREW
28	1	649350	SCREW
29	1	649351	AIR FILTER ELEMENT
30	1	415372	AIR FILTER ASS'Y
31	1	649355	LEVER
32	1	649356	VALVE
33	1	649358	SCREW
34	1	649353	CYLINDER GASKET
35	1	649354	AIR FILTER COVER
36	1	415373	MUFFLER ASS'Y
37	1	400927	SPARK ARRESTER
38	1	400918	SCREW
39	1	649359	O-RING
40	2	649360	BOLT
41	2	414450	BOLT SOCKET
42	2	414451	SCREW
43	1	414452	SCREW
44	1	414453	FUEL TANK CAP ASS'Y
45	1	649362	BREATHER
46	1	649364	TANK CAP ASSY
47	1	625872	FILTER FUEL
48	1	632199	JOINT
49	1	944177	CLAMP
50	1	597949	FUEL FILTER
51	2	649366	CLAMP
52	1	649369	TUBE3X5X305
53	1	415375	Tube
54	1	649368	TUBE2.3X5X93
55	2	649365	CLAMP
56	1	415374	Priming Pump
57	1	212250	CONNECTER
58	1	649337	THROTTLE CABLE
59	1	598438	LABEL





Picture Number	Quantity	Part number	Description
1	1	123413	FLEXIBLE PIPE
2	1	125145	PIPE ASSY
3	1	122395	SWIVEL PIPE
4	1	122400	STRAIGHT PIPE
5	1	125146	CONE PIPE
6	1	128188	Clamp Ass'y
7	1	128189	Clamp Ass'y
8	1	125439	HIP BELT ASSY
9	1	127099	Box Spanner
10	1	125942	Instruction Manuel